



Overview

Product name	iQ-Multispectral
Principle	<p>Diffuse light panels that use iQ-LED technology (includes a micro-spectrometer) to illuminate a reproducible scene for multispectral imaging.</p> <p>The iQ-LED technology is optimized for the best spectral match and allows CRI values up to 99 depending on the illuminant and intensity. For multispectral imaging, every LED channel can be used in a single mode.</p> <p>The iQ-Multispectral has a separate UV channel that is optionally combinable with a UV bandpass filter to give it the best performance in UV imaging.</p>

Features

Diffuse light panel

Light area (per panel)	650mm x 135mm
------------------------	---------------

Illumination

Light source (per panel)	<p>2 x iQ-LED V2 3 x iQ-LED IR 2 x iQ-LED UV</p> <p>Image Engineering iQ-LED V2 technology:</p> <p>iQ-LED V2: 41 SMD high power LEDs / Separated in 20 color channels / Spectral range: 380 – 820 nm / Intensity controlled via 4000 steps per channel and 32 kHz PWM (switchable to 1000 steps with 128 kHz) / Approx. lifetime of 10,000 hrs. iQ-LED IR: 11 additional channels, expands the spectral range to 380 – 1050 nm iQ-LED UV: 2 SMD high power LEDs (365 nm plus bandpass filter)</p> <p><i>Measurement of typical single channel spectra on request</i></p>
--------------------------	--



Optional bandpass filter for UV channel	350 nm Hard Coated Bandpass Interference Filter 50nm FWHM 365 nm Hard Coated Bandpass Interference Filter 10nm FWHM
Control functionality without PC	Store up to 44 different illuminants and one sequence on the device, default light source, controllable via micro switches on the device without PC, on/off switch for UV channel
Uniformity in the scene	Up to 90% for A2 space
Illumination stability	+/- 1% when stabilized (2% after switching D illuminants in the first 5 seconds)
Response time (switch illuminant)	< 50 ms

Maximum / Minimum illumination level (two panels in a scene)	Up to 2000 lx for standard D illuminants in A3 scene Up to 1200 lx for standard D illuminants in A2 scene Min. down to 25 lx for standard D illuminants
Dim function	Software-based by presetting the intensity, or by selecting different pre-stored intensity illuminants directly on the device
Predefined standard illuminants	D50, D55, D65, D75, A, B, C, E Planckian spectral curve by selected temperature (1900 - 18,000 K)
Service life	10,000 hrs.

Spectrometer

Construction	Separate calibration device with a spectrometer for easy positioning/fixation to measure in the scene
Spectral range	200 -1100nm
Pixel resolution	2048 pixel
FWHM	2.5nm
Output data	Real-time measurement of spectral trend and radiant power via control software while the calibration device is in the measuring position
Calibration	Yearly calibration required independent of working hours (contact Image Engineering), NIST traceable

Software

System requirements	PC with Windows 7 operating system (or higher) 2 x USB port
Functions	<ul style="list-style-type: none"> • Auto-generation of standard illuminants or externally measured spectra • Creation or adaptation of spectral trends via 31 LED channels • Additional narrowband UV channel • Save and load function of self-defined spectral arrangements or intensities • Storage of illuminants/sequences on device • Creation of test sequences • Real-time display of spectral measurement



	<ul style="list-style-type: none"> • Real-time calculation of CCT, CRI, curve fit and illumination level • Separate dim functionality for UV channel
API (C++)	Available as a separate option (iQ-LED API)

General description hardware

Power supply / consumption	210 - 230 V / 230W
Ports (per panel)	1 x USB for software control 1 x port for power adaptor 1 x 3.5 mm jack for trigger output
Dimension [W x H x D] (per panel)	665 mm x160 mm x 130 mm
Weight (per panel)	5.8 kg
Operating conditions	Optimal: 22 - 26 degrees Celsius, maximal: 18 - 28 degrees Celsius
Warm-up time	< 2 min at an optimal ambient temperature
Positioning / Fixation	Easy positioning with swivel arm. Fixation via 25x25 mm profile (min. 600 mm length) or 3/8" tripod mount. With additional Kaiser parts in a complete repro setup.
Scope of delivery	Pair of iQ-Multispectral panels with swivel arms, calibration device, 2 x power cord, USB cable, control software, calibration protocol
Additional parts	Complete Kaiser repro setup (on request)

Safety instructions



WARNING OF OPTICAL RADIATION!

According to “IEC 62471-2:2009 - Photobiological safety of lamps and lamp systems” the **iQ-Multispectral** is classified as **Risk Group 3**, due to some LEDs emitting invisible light in the “IR” as well as the “UV” region of optical radiation.

RISK GROUP 3



- **WARNING. UV emitted from this product. Possibly hazardous optical radiation emitted from this product. Do not look at operating lamp. Eye injury may result.**
- **WARNING. IR emitted from this product. Do not look at operating lamp.**